

# wecler ESSENTIALS

## ePINBLU

AUDIO ACCESSORIES

*Wireless Audio Receiver*



## QUICK GUIDE

## Start-up

In order to pair your ePINBLU with other wireless devices, you must bring the ePINBLU into pairing mode:

1. Hold the LED button (PLAY / PAUSE) for 2 seconds until the LED flashes red and blue alternately.
2. Activate Bluetooth on your device and set it to search for new devices.
3. Select "Ecler ePINBLU" on your device.

NOTE: if necessary, enter the password: 0000 or 8888 to connect.

## Multi-function button

Function	Operation	LED indicator
Power ON	Hold the LED button for 2s. until the LED flashes blue	It will flash blue, then will flash red and blue
Power OFF	Hold the LED button for 2s. until the LED flashes red	It will flash red at first, then turn off
Play	Press LED button once	It will flash blue every 4s.
Pause	Press LED button once	It will flash blue twice every 4s.
Pairing mode	Hold LED button for 2s.	It flashes red and blue alternately
Volume +/-	Hold "+ / -" button	It flashes blue once every 4 s. to indicate working status
Prev. / next song	Press "+ / -" button	