

1. Plug in CORE transmitter

Connect the transmitter DC adapter to the electrical outlet and use one of the 3 available audio inputs to connect the music source

2. Insert TUBE in the lighting rail

Rotate the safety lug to secure the loudspeaker on the lighting rail

3. Power ON TUBE

Rotate the wheel to match with the electric phase of the lightning rail

Check whether the unit is really powered or not by watching the LED indicators at its rear panel. If the green LED start blinking the unit is ready to pair(*)

(*) Otherwise, push & hold for 5 seconds the PAIR button at the back panel of the unit. After that, both LEDs will blink, meaning that the unit is now ready to pair

4. Pair the devices

Make a short press on the WiS PAIR key (using a clip e.g.), the WiS and RX LEDs will start to blink

When CORE and TUBE lights stop blinking, the devices are paired

5. Select the input and play the music!

WiSpeak grip



Use WiSpeak grip app for set up and control functions

